Shared Studio Leg | Indiana

Assembly Instructions

Components:

- Shared Studio Legs (Qty 2)
- #8 x 5/8 PPH Screw (Qty 16)
- Attach legs centered on the seam of adjoining units as shown.

It is critical that the legs are attached to the outside ends.

There are four holes that should line up down the center of each end panel.

Also be sure to align front legs with the front of the bottom panel.

Do not attach to the bottom edge of door.

