



Run-Off & Table Desk Modesty Assembly Instructions

Components:

- 1 – Modesty Panel
- 18 – Screw #6 x 1/2 PPH DT Ziinc
- 3 – 9" Silver L-Brackets

- 1 Attach L-Brackets spaced evenly flush to top edge of modesty using 5/8" screws
- 2 Center Modesty between legs on table desk or with the leg/overall surface on run-off table desk and fasten to undersurface of top using 5/8" screws
- 3 The table desk modesty should be fully assembled.

