



Modular Double Bookcase with Base and Top Assembly Instructions

Components:

- 28 – Screws, #8 x 1 3/8" PFH

Units Required:

- 2 – Modular Bookcase
- 1 – Modular Double Bookcase Base
- 1 – Modular Double Bookcase Top

1 Stand bookcases upright next to each other.

2 Align the top edges flush, and the face edges flush (of the bookcases).

You may have to use a bar clamp to a strap clamp to temporarily hold the cases tightly together.

3 Drill pilot holes and insert screws and fasten the two bookcases together.

Placement of screws and amount of screws is decided by installer.

4 Drill 6 pilot holes in the top panel of each of the bookcases.

5 Insert screws through previously drilled pilot holes in the top panel of the bookcases and fasten to top as shown. (approximate 3/4" spacing around edges of the top)

6 To assemble base unit place bookcase upside down, and align base assembly to the bookcase. Then insert screws through mounting strips.

7 Insert levelers into base assembly, and adjust as needed.

