



Modular Double Bookcase with Top Assembly Instructions

Components:

- 12 – Screws, #8 x 1 3/8" PFH

Units Required:

- 2 – Modular Bookcase
- 1 – Modular Double Bookcase Top

- 1 Stand bookcases upright next to each other.
- 2 Align the top edges flush, and the face edges flush (of the bookcases).

You may have to use a bar clamp to a strap clamp to temporarily hold the cases tightly together.

- 3 Drill pilot holes and insert screws and fasten the two bookcases together.

Placement of screws and amount of screws is decided by installer.

- 4 Drill 6 pilot holes in the top panel of each of the bookcases.
- 5 Insert screws through previously drilled pilot holes in the top panel of the bookcases and fasten to top as shown. (approximate 3/4" spacing around edges of the top)
- 6 Attach no slip tape to the bottom of each bookcase.
- 7 Place unit on top of the desired base unit.

