



Modular Single Bookcase With Top Assembly Instructions

Components:

- 6 – Screws, #8 x 1 3/8" PFH

Units Required:

- Modular Bookcase
- Modular Bookcase Top

- 1 Drill 6 pilot holes in the top panel of the bookcase.
- 2 Insert screws through the previously drilled pilot holes in the top panel of bookcase and fasten to top as shown. (approximate 3/4" spacing around edges of the top)
- 3 Attach no slip tape to the bottom of each bookcase.
- 4 Place unit on top of the desired base unit.

