

## Flush Return Assembly Instructions

### Components:


- 16 – Screws, #8 x 5/8" PPH
- 1 – Z Bracket
- 2 – 4" x 4" Flat Plates

### Applies to:


- Return Unit & Pedestal Desk
- Return Unit & Credenza
- Return Unit & Corner Unit
- Return Unit & P-Top / D-Top

- 1 Attach the two 4 x 4 flat plates to the underside of the top as shown in the top view. (use the #8 x 5/8" screws for this application)
- 2 Attach the return back panel to the desk end panel using the Z-bracket. Ensure the return back panel is flush with the desk end panel on the outside face.

UNDERSIDE OF TOP VIEW



SIDE VIEW



**Pictures Show Left Return, Right Return is Reversed.**