



Phoenix | Indiana FURNITURE

Bridge Unit Brackets Assembly Instructions

Components:

- 8 – Screws, #8 x 5/8" PPH
- 10 – Screws, #10 x 7/8" PPH Zinc
- 2 – Flat Plates 2" x 6"
- 4 – Flat Plates 4" x 4"

Applies to:

- Credenza & Bridge Unit & Pedestal Desk
- Corner Unit & Bridge Unit & Credenza
- Corner Unit & Bridge Unit & Pedestal Desk

1 Attach the (2) 4 x 4 flat plates to the underside of the top as shown in the top view on each end of the bridge top. Use #10 x 7/8" zinc screws.

2 Use #8 x 5/8" black screws to attach 2 x 6 flat bracket to bridge back panel, desk end panel, and credenza panel as shown in front view.

