

## Assembly Instructions

### Components:

- Studio Legs (Qty 4)
- #8 x 5/8 PPH Screw (Qty 20)

#### 1 Attach legs as shown.

It is critical that the legs are attached to the outside ends.

Also be sure to align front legs with the front of the bottom panel.

Do not attach to the bottom edge of the door.

