

Height Adjustable Cabinet Leg | Indiana FURNITURE

Assembly Instructions

Components:

- Cabinet with Leg
- Worksurface (HTP model)
- T-Support
- Top Mount L-Brackets (Qty 2)
- #10 X 7/8 PPH Zinc Screws (Qty 12)
- M6-16mm Black Screws (Qty 6)
- Post for Mounting Wire Management Sleeve (Qty 4)

1 Attach T-support and L-Brackets to Height Adjustable Leg using M6-16mm screws.

2 Attach worksurface by lining up L-Bracket holes with the highlighted holes shown below. Use #10 X 7/8 PPH Screws provided.

3 Fill remaining eight L-Bracket holes and four T-Support holes. Use #10 X 7/8 PPH screws provided.

(Please note we only have alignment markers for the first four holes. All other markers are for other applications.)

4 Insert four Posts in highlighted locations for mounting the sleeve.

5 Slide 3-sided sleeve onto posts attached to top. Turn cams Clockwise with screwdriver to lock into place.

6 Align tree lock plugs with holes in mounting brackets...press to connect face.

