

# HA Panel Leg with Sleeve | Indiana FURNITURE

## Assembly Instructions

### Components:

- Height Adjustable Panel Leg w/Sleeve
- Worksurface (HTP model)
- T-Support
- Top Mount L-Brackets (Qty 2)
- #10 X 7/8 PPH Zinc Screws (Qty 12)
- M6-16mm Black Screws (Qty 6)
- Post Connectors (Qty 4)
- Figure 8 Brackets (Qty 2)

**1** Attach T-support and L-Brackets to Height Adjustable Leg using M6-16mm screws.

**2** Attach worksurface by lining up L-Bracket holes with the highlighted holes shown below. Use #10 X 7/8 PPH screws provided.

**3** Fill remaining eight L-Bracket holes and four T-Support holes. Use #10 X 7/8 PPH screws provided.

*(Please note we only have alignment markers for the first four holes. All other markers are for other applications.)*

**4** Insert four Posts in highlighted locations for mounting the sleeve.

**5** Slide 3-sided sleeve onto posts attached to top. Turn cams Clockwise with screwdriver to lock into place.

**6** Attach sleeve face using provided L-Brackets and 2 figure 8 brackets on the bottom edge.

