



# Modular Double Bookcase with Cornice Frame Assembly Instructions

## Components:

- 12 – Screws, #8 x 1 3/8" PFH

## Units Required:

- 2 – Modular Bookcase
- 1 – Modular Double Overhead Cornice Frame

- 1 Stand bookcases upright next to each other.
- 2 Align the top edges flush, and the face edges flush (of the bookcases).

**You may have to use a bar clamp to a strap clamp to temporarily hold the cases tightly together.**

- 3 Drill pilot holes and insert screws and fasten the two bookcases together.

**Placement of screws and amount of screws is decided by installer.**

- 4 The molding that protrudes out farther is designed to be the top of the cornice frame.
- 5 Center the cornice frame from side to side, then ensure that with the back edge of the bookcase and cornice frame are flush
- 6 Insert screws through the mounting rails in the cornice frame and fasten to the top of the bookcase.

