

# 4" and 7" Modesty Panel Installation Instructions 2298-66009

## Parts List:

2 - Modesty L Brackets  
24 - Screw #10 X 5/8 PPH

**Step 1:** Screw brackets to Modesty panel using holes provided on back of panel. (6 Screws #10 X 5/8 PPH)

**Step 2:** Place Modesty under Desk Top and center left to right. Modesty can be flush with Desk Top or it can be recessed. Screw brackets to top panel. (6 Screws #10 X 5/8 PPH)

