



Above + Below Screen | Indiana FURNITURE

Assembly Instructions

Components:

- L Brackets
- Screw #8 x 5/8 PPH DT Black

- 1 Place panel against top holding 12" from work surface to top of privacy panel.
Center panel left to right.
- 2 Using "L" brackets attach to the bottom of the work surface top and to the privacy panel.

