



Single Column Bridge Assembly Instructions

Components:

- 1 – 2500mm Cable
- 2 – Flat Brackets and Screws
- 2 – Z Brackets and Screws
- 1 – Single Ped Desk
- 1 – Single Column Bridge
- 2 – Wire management channels

① Align and attach bridge back to wing end on desk with 2 - Z brackets or flat brackets depending on thickness of end panel. Align top panels and attach 2 flat brackets.

② Locate the 2500mm Cord and feed one end thru the grommet on the end panel of bridge.

③ Take opposite end of 2500mm cord and run thru the grommet in false ped face of desk and thru grommet in kneespace to plug into the control box.

④ Apply wire management trays as desired.

