



U-Group Assembly Instructions

Components:

- 4 – 4" Flat Brackets (Included with Return)
- 20 – 7/8" Screws (Included with Return)
- 2 – Z Brackets (Included with Return)
- 8 – 5/8" Screws (Included with Return)
- Double Sided Tape (Included with Hutch)

- 1 Align top panels and attach flat brackets with 7/8" screws.
- 2 Align and attach bridge back to wing end on desk and wing end on credenza with Z bracket and 5/8" screws.
- 3 Apply double sided tape to bottom edges of surface mounted hutch.
- 4 Carefully place the surface mounted hutch on the top surface in the desired location. Once placed the hutch cannot be moved without possible damage to the surface.

