



# Flip/Nest Base Assembly Instructions

## Components:

- Spark T-Leg Flip/Nest Base Assembly Kit
- Spark Training Table Surface For Flip/Nest Base
- 1" PPH Screws

- 1 Place Flip/Nest Base Assembly on bottom surface and align with peck holes.
- 2 Use 1" PPH screws to secure Flip/Nest Base and Handle to top in locations shown.
- 3 Squeeze handle to release Flip/Nest Base and rotate the flip assembly up to reveal additional mounting holes. Secure using 1" PPH screws.
- 4 Assemble T Legs to Flip/Nest Base using hardware provided in the Flip/Nest Base Assembly Kit. Ensure Wire Management cutouts on legs are pointed towards the middle of the table.
- 5 Secure Flip/Nest cables using hardware included in the Flip/Nest Base Assembly Kit as needed.

